

27

Whole Lobster (Fresh)



EQUIPMENT

- Sonic Steamer (NE-3280 or NE-2180)
- 1 full size or 1½ size 4" pans with covers

PROCEDURE

- 1 Place Lobsters in appropriate pan and cover
- 2 Place pan in Sonic Steamer.
- 3 Press POWER to set HIGH, using dial set time then press START.

Lobster Weight-Range (Lbs.)	NE-3280									
	Amount (Each, FRESH)									
	1	2	3	4	5	6	7	8	9	10
1.00 - 1.24	N/A	2:10	4:00	5:30	6:30	7:30	8:30	9:30	11:00	13:00
1.25 - 1.49	N/A	4:00	5:30	6:30	7:30	8:00	9:00	11:00	13:00	14:00
1.50 - 1.74	2:30	4:30	6:00	7:00	8:00	9:00	11:00	13:00	14:00	15:00
1.75 - 1.99	3:00	5:00	6:30	7:30	9:00	10:00	N/A	N/A	N/A	N/A
2.00 - 2.24	3:30	5:30	7:30	8:30	9:30	11:00	N/A	N/A	N/A	N/A
2.25 - 2.49	4:00	6:00	8:00	9:00	10:00	12:00	N/A	N/A	N/A	N/A
2.50 - 2.99	4:30	7:30	9:00	10:00	11:00	13:00	N/A	N/A	N/A	N/A
3.00 - 3.99	5:30	8:30	10:00	11:00	12:00	14:00	N/A	N/A	N/A	N/A
4.00 - 5.00	6:00	9:00	11:00	12:00	14:00	17:00*	N/A	N/A	N/A	N/A

Lobster Weight-Range (Lbs.)	NE-2180									
	Amount (Each, FRESH)									
	1	2	3	4	5	6	7	8	9	10
1.00 - 1.24	N/A	2:50	5:10	7:00	8:00	9:00	11:05	12:20	14:20	16:55*
1.25 - 1.49	N/A	5:00	6:30	7:30	9:00	10:00	11:40	14:20	16:55*	18:10*
1.50 - 1.74	3:30	5:30	7:30	8:30	9:30	11:00	14:20	16:55*	18:10*	19:30*
1.75 - 1.99	4:00	6:00	8:00	9:00	10:00	12:00	N/A	N/A	N/A	N/A
2.00 - 2.24	4:30	7:30	9:00	10:00	11:00	13:00	N/A	N/A	N/A	N/A
2.25 - 2.49	5:30	8:30	10:00	11:00	12:00	14:00	N/A	N/A	N/A	N/A
2.50 - 2.99	6:00	9:00	11:00	12:00	14:00	17:00*	N/A	N/A	N/A	N/A
3.00 - 3.99	6:30	10:00	12:00	14:00	16:00*	19:00*	N/A	N/A	N/A	N/A
4.00 - 5.00	7:00	11:00	13:00	16:00*	18:00*	21:00*	N/A	N/A	N/A	N/A

NOTE: For times above that are greater than 15:00 - press "Power" again and dial up the remaining time (15:00+4:00=19:00)